

ARTICULIGHT

15-06 Morlot Avenue, Fair Lawn, NJ 07410 USA Tel: (201) 796-2690 Fax: (201) 796-8818

info@articulight.com

articulight@aol.com

www.articulight.com

LED SERIES

SRC-AI-100



ADDRESS CODE WRITER/SYNCHRONIZER



ADDRESS CORE WRITER is a combination of DMX address writer and synchronous controller. It is suitable for writing address and controlling SPECTACOLOUR WALL WASHER, LED AQUA, LED TILE series. It is a versatile and user-friendly controller.

Power up the DMX 512 controller, then the LCD display:

RW-ADDR [UP]

Controller [DOWN]

Press key 'UP', then the system is in address writing mode, press the 'DOWN' key, then the system is in controlling mode; if there is no operation on the controller in ten seconds, it will come into the controlling mode automatically.

Instructions for the power operation:

1. The interior battery is for writing address only when there is no exterior power supply.
2. When DMX 512 is used as controller, a power supply of 12V3A is needed.
Note: When it is used as controller, do not surpass the power consumption.

DUE TO CONTINUOUS IMPROVEMENTS, SPECIFICATIONS MAY CHANGE WITHOUT PRIOR NOTICE.